

# Getting Started with the Quest 2 Kit

Dear staff member,

Thank you for requesting this kit! We recommend you spend at least 30 minutes familiarizing yourself with how everything works before hosting a program with patrons. Before jumping in, take a few moments to unload the kit. Please pay particular attention to the binder, which contains some crucial information. **Please read the following binder sections carefully, because you are responsible for creating and maintaining a safe environment for use at all times:**

- **Read Before Using (for Library Staff)**
- **Quest 2 Safety Manual**
- **User Agreements and Waivers** (copy these out of the binder or print from the USB. We do not need you to send us the signed documents - they are for your library's records.)

Once you are ready to try the headset:

- Make sure you have ample space around your chair (try starting with a swivel chair that has 6 feet of clear space around it).
- Turn the headset on (the **on button** is on the right when wearing the headset, and **volume** is controlled on the bottom of the headset). The Quest 2 will walk you through getting connected to WiFi and then guide you through set up/orientation. You can always go back to the 'First Steps for Quest 2' app to refamiliarize yourself (or new users) with how everything works.
- Take this opportunity to also connect the iPad to WiFi, as this can be used to "cast" what the headset user is seeing and hearing, allowing for more insightful demonstrations in group settings.

**Note for glasses wearers:** To get the best viewing experience possible, you will want to keep your glasses on (or else it might be blurry for your particular vision) and make use of the glasses spacer included in the kit. If you notice a lot of blurriness even while wearing glasses, try repositioning the headset until the lenses are exactly centered on your pupils (this can take some trial and error and subtle changes in the headset's placement can make a big difference).

**Note on appropriate content:** The Quest 2 is **designed for users aged 13 up**. Be cognizant of the fact that the headset and iPad will both be connected to the internet and some of the content to be found there can be unsuitable for younger audiences. We have not put any restriction on the apps/experiences that can be run on the device as we want to give you the ability to explore as you like.

**Troubleshooting:** Guidance on how to use the headset and troubleshoot common problems can be found within the binder or in the *Quest 2 Complete Guide* book. Guidance can be easily found on the Meta Quest 2 website or by simply searching your question on Google/Youtube (easily access the internet using the iPad).

**Feel free to reach out to us at any time at [kitsupport@coloradovirtuallibrary.org](mailto:kitsupport@coloradovirtuallibrary.org).**